



# MODULAR RAMP SYSTEM



PVI has designed a modular, all aluminum ramp system, for both home access and commercial use. This 36 inch wide ramp system has a load carrying capacity of 100 pounds per square foot. The ramp system consists of standard components that can be assembled quickly and easily with common hand tools. The modular components make it easy to move the ramp to a new location or change the configuration. Straight ramps, 90 degree turns, and 180 degree switchbacks are designed to meet ADA recommendations.

Standard handrails consist of two 1½ inch diameter horizontal rails. PVI offers optional handrail designs. This system is able to accommodate architectural inserts to complement the surroundings.

The PVI modular ramp system is strong, durable, portable, flexible, and yet is affordable enough to make it the best alternative to provide quality, functional access to many areas.

## “Modular Ramp System” Specifications

<b>Width:</b>	36 inches
<b>Length:</b>	As required – 4 foot minimum
<b>Load Capacity:</b>	100+ pounds per square foot
<b>Slope:</b>	Adjustable – as required
<b>Floor:</b>	Slip resistant grooved aluminum
<b>Edge Protection:</b>	2 inch curb
<b>Handrails:</b>	Double 1½” bar – standard Height: 36” - 38”

Other Designs available upon request.