

# Clearway™

**RICON**®  
INNOVATION IN MOBILITY™



- Exclusive split-platform design allows clear access to the vehicle's interior
- Powerful hydraulic pump ensures smooth, stable operation for heavy wheelchairs and scooters
- All-steel frame features convenient handrails for increased comfort and security

***The Most Reliable Personal Platform Lift***



# Clearway™

## Clearway™ Advantages:

- Unique split-platform design permits access through the doorway
- Stable, non-skid platform with automatic inboard and outboard rollstops accommodates most wheelchairs and scooters
- Pre-lubricated bearings at all major pivot points offer long-term durability
- High gloss, polyester powder coat finish resists corrosion
- Efficiently designed electrical system and powerful hydraulic power pack provide years of trouble-free operation
- Built-in manual backup system
- Optional easy-to-use accessories include:
  - Internal swing door operator
  - Sliding door operator
  - Power remote control



## Lift Specifications:

Power Source .....	Electro Hydraulic Motor
Rated Load Capacity .....	800 lbs.
Manual Backup - Up .....	Manual Hand Pump
Manual Backup - Down .....	Manual Release Valve
Weight .....	285 lbs.

*"As I always say, 'doing your best is a lifetime job'... and Ricon makes that job easier with their commitment to mobility and accessibility for people who use wheelchairs and scooters."*

### **Skip Wilkins**

*Author, Lecturer, International Athletic Competition Gold Medal Winner, National Wheelchair Athlete of the Year.*

